


FTTH Wall outlet

euroclust offers two types of wall outlets


The wall outlet is used to terminate optical installation cables to pigtails at subscribers premises. The cable is fed to the wall outlet from the left side, right side or from the back. The wall outlet consists of body, splice cassette, cover and lid. The body is fixed to the wall with screws and is used for entrance and routing of the optical installation cable and mounting of optical adapters. The purpose of the splice cassette is to take excess lengths of optical cables and to fix splice protectors (1-2 pcs). Heat-shrink splice protectors or coldsplice protectors (mechanical splices) can be fixed easily on the splice cassette. A cover protects the contents of the wall outlet. The wall outlet is made of White (RAL 9010) High Heat and High Impact Resistance Polystyrol (PS454C). Optionally the euroclust wall outlets can be delivered with

- **Optical adapter SC/UPC (blue) or Optical adapter SC/APC (green)**
SCsx adapter with plastic housing with ceramic sleeve (ZrO₂); IEC 61754-4, TIA 604-3 compliant
- **Pigtail SC/UPC or APC L=1m semi-tight buffered construction;**
900µm outer diameter. Fiber Type 9/125 SM ITU-T G.657.A
(IL<=0,3dB; RL>=-50dB UPC, RL>=-65dB APC) IEC 61754-4, TIA 604-3 compliant

Wall outlet standard



Wall outlet mini



Ordering Information wall outlet standard

Empty wall outlet

<i>Description</i>	<i>Type</i>	<i>ec- Article Nr.:</i>
Wall outlet for 2 SC sx adapters empty	TBWO/E2SCSX	EC05.200000.001

Assembled with Adapters only

Wall outlet with 1 SC/UPC sx Adapter		EC05.200001.011
Wall outlet with 1 SC/APC sx Adapter		EC05.200001.013
Wall outlet with 1 SC/UPC sx swing shutter Adapter		EC05.200001.039
Wall outlet with 1 SC/APC sx swing shutter Adapter		EC05.200001.041
Wall outlet with 1 SC/UPC and 1 SC/APC sx Adapter		EC05.200001.001
Wall outlet with 1 SC/UPC and 1 SC/APC sx swing shutter Adapter		EC05.200001.033
Wall outlet with 2 SC/UPC sx Adapter		EC05.200001.003
Wall outlet with 2 SC/APC sx Adapter		EC05.200001.005
Wall outlet with 2 SC/UPC sx swing shutter Adapter		EC05.200001.035
Wall outlet with 2 SC/APC sx swing shutter Adapter		EC05.200001.037

Assembled with Adapters and Pigtailed

Wall outlet with 1 SC/UPC sx Adapter + Pigtail		EC05.200001.012
Wall outlet with 1 SC/APC sx Adapter + Pigtail		EC05.200001.014
Wall outlet with 1 SC/UPC sx swing shutter Adapter + Pigtail		EC05.200001.040
Wall outlet with 1 SC/APC sx swing shutter Adapter + Pigtail		EC05.200001.042
Wall outlet with 1 SC/UPC and 1 SC/APC sx Adapter + 2 Pigtailed		EC05.200001.002
Wall outlet with 1 SC/UPC and 1 SC/APC sx swing shutter Adapter + 2 Pigtailed		EC05.200001.034
Wall outlet with 2 SC/UPC sx Adapter + 2 Pigtailed		EC05.200001.004
Wall outlet with 2 SC/APC sx Adapter + 2 Pigtailed		EC05.200001.006
Wall outlet with 2 SC/UPC sx swing shutter Adapter + 2 Pigtailed		EC05.200001.036
Wall outlet with 2 SC/APC sx swing shutter Adapter + 2 Pigtailed		EC05.200001.038

Ordering Information wall outlet mini

Empty wall outlet

<i>Description</i>	<i>Type</i>	<i>ec- Article Nr.:</i>
Wall outlet for 2 SC sx adapters empty	TBWOS/E2SCSX	EC05.200010.000

Assembled with Adapters only

Wall outlet with 1 SC/UPC sx Adapter		EC05.200010.011
Wall outlet with 1 SC/APC sx Adapter		EC05.200010.013
Wall outlet with 1 SC/UPC sx swing shutter Adapter		EC05.200010.039
Wall outlet with 1 SC/APC sx swing shutter Adapter		EC05.200010.041
Wall outlet with 1 SC/UPC and 1 SC/APC sx Adapter		EC05.200010.001
Wall outlet with 1 SC/UPC and 1 SC/APC sx swing shutter Adapter		EC05.200010.033
Wall outlet with 2 SC/UPC sx Adapter		EC05.200010.003
Wall outlet with 2 SC/APC sx Adapter		EC05.200010.005
Wall outlet with 2 SC/UPC sx swing shutter Adapter		EC05.200010.035
Wall outlet with 2 SC/APC sx swing shutter Adapter		EC05.200010.037

Assembled with Adapters and Pigtails

Wall outlet with 1 SC/UPC sx Adapter + Pigtail		EC05.200010.012
Wall outlet with 1 SC/APC sx Adapter + Pigtail		EC05.200010.014
Wall outlet with 1 SC/UPC sx swing shutter Adapter + Pigtail		EC05.200010.040
Wall outlet with 1 SC/APC sx swing shutter Adapter + Pigtail		EC05.200010.042
Wall outlet with 1 SC/UPC and 1 SC/APC sx Adapter + 2 Pigtails		EC05.200010.002
Wall outlet with 1 SC/UPC and 1 SC/APC sx swing shutter Adapter +2 Pigtails		EC05.200010.034
Wall outlet with 2 SC/UPC sx Adapter + 2 Pigtails		EC05.200010.004
Wall outlet with 2 SC/APC sx Adapter +2 Pigtails		EC05.200010.006
Wall outlet with 2 SC/UPC sx swing shutter Adapter +2 Pigtails		EC05.200010.036
Wall outlet with 2 SC/APC sx swing shutter Adapter + 2 Pigtails		EC05.200010.038